




Energizer® Pro 3 LED Headlight
Energizer® Pro 6 LED Headlight
Instruction Sheet

BATTERY INSERTION / REPLACEMENT INSTRUCTIONS:



1. Insert and twist a coin in the battery access panel on back of headlight.
2. Insert batteries according to the orientation markings on the inside of the battery cavity.
3. Replace battery cover and snap closed.

Energizer®

Mfd. for:
Energizer Holdings, Inc.,
St. Louis, MO 63141
© 2012 Energizer